




Shingle & Header Cap




$11/16 \times 2 \frac{1}{4}, 2 \frac{1}{2}$




$11/16 \times 1 \frac{5}{8}, 2$




$11/16 \times 1 \frac{3}{8}$




9350
 $1 \frac{1}{2} \times 2 \frac{3}{4}$




$2 \frac{1}{4} \times 2 \frac{3}{8}$




$7/8 \times 1 \frac{5}{8}$



$3/4 \times 1 \frac{3}{4}$




$1 \frac{3}{8} \times 2$



9355

$1 \frac{5}{8} \times 2 \frac{1}{2}$




9356

$1 \frac{3}{8} \times 2 \frac{9}{16}$




Fraser
Millworks


Shingle & Header Cap




9357
1 1/2 x 2 1/4




9358
1 15/16 x 1 9/16



9360
1 x 1 3/4



9359
1 5/16 x 2 9/16



9362
1 1/4 x 2 3/16




9361
1 7/8 x 6 3/4




Fraser
Millworks


Shingle & Header Cap




9363
1 1/8 x 2 1/2




9364
2 13/16 x 3 1/2




9365
2 1/16 x 2 1/4



9367
2 x 2 3/4



9366
1 3/8 x 2 5/16



Fraser
Millworks